




E228#



E026#



E028#



E200#



E350SS#



E254#



E500SS#



E029#



E030#



E620SS#

02-Eyelet W Washer

.....



E078#



E004#



E003#



E002#




E100#



E020#



E020W#



E125#




E022#



E023#



E024#



E180#

Double Side Eyelet

.....



E004D



E002D



E020D



E120D



E022D



E023D



E024D



E026D

03-OVAL EYELE W WASHER




OE150



OE170




OE190



OE210



OE230



OE250




E120-LA066



Wh3784

BUCKLE



WH2032



WH2033



WH2034



WA4331

S392#-150



S392#-170



S392#-170TC



S392#-200



S392#-250



S392B#-150



S392B#-170



S392C#-150



S392C#-170



S703#-170



S705#-125



S212B#-125



S213#-125



S419#-125



S312#-125



S315#-150



11-GERMANY SNAP BUTTON

S317#-170



S320#-200



S417#-170



S517#



S520#



12-GERMANY SNAP BUTTON

DOUBLE TWIN SNAP BUTTON

S4061#



S4051#



ONE WAY OPEN SNAP BUTTON

S385#-150



S384#-150



S390#-125



S208B#-115



S208C#-125



S209C#-150



S705#-150




15-FISH EYE CAP SNAP BUTTON

S409A#-170




S401#-170



S402#-190



S407#-180



16-STANDARD SNAP BUTTON

S406#-125



S405#-150



S108#-080



S488#-100



S486#-140



S484#-170



17-STANDARD SNAP BUTTON

S8050#-150



S586#-150



S584#-170



BRASS CAP OPTIONS



10



11



12.5



14



15



17

Hidden Cap



20



25



12.5



14



15



17



10



11



12.5



14



15



20



17



23



19



25



10



11



12.5



14



16



20



17



23



19



25



12.5



12.5



12.5



15



15



15



17



17



17



20



20



20



23



23



23



25



25



25

